

## EcoBorder Curb Drilling Template

Instructions: Cut along dotted line with scissors. Drill through the black dots with a 3/16" drill bit to create new connector holes.

